

LUUM

Care for Polyurethane Upholstery

General Care + Maintenance

- Regular, light dusting with a microfiber cloth.
- Vacuum regularly with a clean, soft brush upholstery attachment.
- Clean stains and spots promptly using the gentlest methods first.
- Always test the cleaning agent in an inconspicuous area .
- Follow cleaning product instructions.
- DO NOT over saturate with liquid.

Cleaning Codes

W Clean with a water-based cleaning agent. Do not use solvent products.

S Clean with a dry cleaning or solvent-based cleaning agent. Do not use water-based cleaning products.

WS Clean with either a water-based or solvent-based cleaning agent.

Care for High Performance

Polyurethane Upholstery:

Meta Texture

Monotex

Perilune

Synaptic

These fabrics feature Cleangene technology. Cleangene is a stain inhibiting polymer inherent to the material make-up. Unlike topical treatments it does not wear off. These fabrics have been tested using the following cleaners with the results per product listed below:

| Cleaner/Disinfectant | Result |
|--|----------------------|
| Accel® PREvention™ Concentrate | No Effect |
| Accel INTERvention™ RTU | No Effect |
| Asepticare™ TB II (Ecolab®) | Severe Effect |
| Biotrol™ BirexSE® III Disinfectant Concentrate | Slight Effect |
| Bleach-Rite® Disinfecting Spray with Bleach | Not Tested |
| CaviCide™ (Metrex) | Severe Effect |
| CaviWipes™ (Metrex) | Slight Effect |
| Clorox Healthcare® EZ Kill® Quat Disinfectant Wipes | Slight Effect |
| Clorox® Broad Spectrum Quaternary Disinfectant Cleaner | Severe Effect |
| Clorox® Disinfecting Wipes | Slight Effect |
| Clorox EZ Kill Wipes (Clorox Company) | Slight Effect |
| Clorox Healthcare® Bleach Germicidal Wipes | Slight Effect |
| Clorox Healthcare® Hydrogen Peroxide Wipes | Slight Effect |
| Clorox Healthcare® Hydrogen Peroxide Disinfectants | No Effect |
| Diluted Bleach, 10:1 Ratio (Clorox Company) | No Effect |
| Fade-A-Dyne II® (Russ Medical Specialties Inc) | Slight Effect |
| Fantastik® Disinfectant Multi-Purpose Cleaner | Slight Effect |
| Formula 409® Multi-Surface Cleaner | Slight Effect |

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

LUUM

Care for High Performance
Polyurethane Upholstery:
(continued)

| Cleaner/Disinfectant | Result |
|--|----------------------|
| Clorox Green Works® All-Purpose Cleaner | No Effect |
| Healthlink EZ-Kill® - Disinfecting Wipes | Slight Effect |
| Isopropyl Alcohol (Miscellaneous) | No Effect |
| Lysol® I.C.™ Brand Foaming Disinfectant Cleaner | Slight Effect |
| Lysol® I.C.™ Disinfectant Spray | Slight Effect |
| Neutral Disinfectant Cleaner (Ecolab®) | No Effect |
| Oasis® 146 Multi-Quat Sanitizer (Ecolab®) | Not Tested |
| Oasis® Quat 144 (Ecolab®) | Slight Effect |
| Optim 33TB (Virox® Technologies Inc.) | Slight Effect |
| Oxivir® Tb (Diversey™) | No Effect |
| OxyCide™ Daily Disinfectant Cleaner (Ecolab®) | Slight Effect |
| Perisept (SSS Triple S®) | No Effect |
| Purell® Multi-Surface Sanitizer and Disinfectant | No Effect |
| Precise Spray (Caltech Industries) | Severe Effect |
| Sani-Cloth® HB (Discontinued by PDI) | No Effect |
| Sani-Cloth® Plus Germicidal Disposable Cloth | Severe Effect |
| Sani Disinfecting Multi-Surface Wipes (Sani Professional®) | Slight Effect |
| No-Rinse Sanitizing Multi-Surface Wipes | Slight Effect |
| Safetec SaniZide Plus® Germicidal Solution | Slight Effect |
| Simple Green® (Sunshine Makers, Inc.) | Slight Effect |
| KAY® SolidSense Wipes | Slight Effect |

Care for High Performance
Polyurethane Upholstery:
Touch Tone

| Cleaner/Disinfectant | Result |
|---|---------------|
| Bleach: Water (1:10) | Slight Effect |
| 3M™ C. diff Solution Tablets | No Effect |
| CaviCide™ (Metrex) | No Effect |
| Ecolab A-456® II Disinfectant (QC) | No Effect |
| Formula 409® Multi-Surface Cleaner | No Effect |
| Hydrogen Peroxide | No Effect |
| Isopropyl Alcohol (70%) | No Effect |
| Lysol® Disinfectant Spray | No Effect |
| Oxivir® Five 16 Concentrate (Diversey) | No Effect |
| Perisept (SSS Triple S®) | No Effect |
| Sani-Cloth® AF3 Germicidal Disposable Wipes | No Effect |
| Virex® Plus (Diversey™) | No Effect |

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

LUUM

Care for High Performance
Polyurethane Upholstery:
Lithoprint

| Cleaner/Disinfectant | Result |
|--|---------------|
| Bleach: Water (1:10) | Slight Effect |
| Sani-HyPerCide® Germicidal Disposable Wipe | No Effect |
| Sani-Cloth® Bleach Wipes (PDI) | No Effect |
| Clorox Healthcare® Hydrogen Peroxide Wipes | Slight Effect |
| Oxivir® Tb Wipes (Diversey™) | No Effect |
| Virex II 256 (Diversey™) | No Effect |
| Virex® Tb | Slight Effect |
| Lysol® Disinfecting Wipes | No Effect |

Care for High Performance
Polyurethane Upholstery:
Nomad

| Cleaner/Disinfectant | Result |
|---|-----------|
| 3M™ C. diff Solution Tablets | No Effect |
| CaviCide™ (Metrex) | No Effect |
| Ecolab A-456® II | No Effect |
| Formula 409® | No Effect |
| Hydrogen Peroxide | No Effect |
| Isopropyl Alcohol (70%) | No Effect |
| Lysol® Disinfectant Spray | No Effect |
| Sani-Cloth® AF3 Wipes | No Effect |
| Virex II 256 (Diversey™) | No Effect |
| Oxivir® 1 Wipe | No Effect |
| Dispatch Hospital Cleaner Disinfectant Towels with Bleach | No Effect |
| Clorox Healthcare® Hydrogen Peroxide Wipes | No Effect |
| PurOne | No Effect |
| Clorox Healthcare® Bleach Germicidal Wipes | No Effect |
| Spartan BNC-15 | No Effect |
| Sani-Cloth® Bleach Germicidal Disposable Wipes | No Effect |
| Super Sani-Cloth® Germicidal Disposable Wipes | No Effect |
| Ecolab Disinfectant 1 Wipe | No Effect |
| Oxivir® Tb RTU | No Effect |

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

LUUM

| | |
|------------------------|--|
| No Effect | No change in color or surface finish. |
| Slight Effect | A change in color or surface finish only visible at certain angles. |
| Moderate Effect | A change in color or surface finish visible from all angles and directions, but does not appreciably alter the original condition of the material. |
| Severe Effect | A change in color or surface finish, which obviously and markedly alters the original condition of the material. |

For test report showing full results, please contact customerservice@luumtextiles.com

The above evaluations are indicators after laboratory testing performed with proper cleaner/disinfectant usage.

After each application, the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue.

Improper use of cleaners/disinfectants can expedite a product failure and void warranty.

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.