

LUUM

Care for Vinyl Upholstery

General Care + Maintenance

- Regular, light dusting with a microfiber cloth.
- Vacuum regularly with a clean, soft brush upholstery attachment.
- Clean stains and spots promptly using the gentlest methods first.
- Always test the cleaning agent in an inconspicuous area.
- Follow cleaning product instructions.
- DO NOT over saturate with liquid.

Cleaning Codes

- W** Clean with a water-based cleaning agent. Do not use solvent products.
- S** Clean with a dry cleaning or solvent-based cleaning agent. Do not use water-based cleaning products.
- WS** Clean with either a water-based or solvent-based cleaning agent.

Common Soiling Concerns

- Regular light dusting with a clean, dry, microfiber duster (lint free and snag-free cloth) will prevent buildup of dirt and contaminants. The frequency of cleaning depends on the environmental conditions the product is subjected to.
- Luum vinyls are bleach-cleanable. Please refer to the specifications for the style for the bleach to water ratio for the cleaning solution. Always test in an inconspicuous area first. Using a clean, white cloth, dip in clean water and wring out. Gently wipe over the treated area. Always follow the diluted bleach treatment with a clean water rinse.
- Food stains & oils: Absorb as much of the stain as possible with a dry cloth or paper towel first. Using a “lifting” action, blot with a clean, white cloth lightly dampened with 70% Isopropyl Alcohol and then blot dry with another clean dry cloth.
- Difficult stains: Clean the soiled area with 70% solution of isopropyl alcohol and water. It is important to rinse the cleaned area with fresh water after applying the alcohol solution. For more stubborn stains, use Formula 409® commercially available mild detergent following the manufacturer’s instructions carefully. Please note: Detergent should never be used on a regular or repeated basis for normal cleaning. Luum recommends repeated rinsing with clear water after any cleaning procedure.

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

Care for Decoy Vinyl

Decoy is a high-performance phthalate-free vinyl upholstery fabric that has been tested using the following cleaners with the results per product listed below:

Cleaner/Disinfectant	Result
3M™ Quat Disinfectant Ready-to-use Cleaner	Slight Effect
Isopropyl Alcohol - 7:3 dilution	No Effect
Biotrol™ BirexSE® Disinfectant Concentrate	Slight Effect
Bleach - 1:4 dilution	No Effect
Citrace Germicide	Slight Effect
Clorox™ Disinfecting Wipes	No Effect
Clorox™ EZ Kill Wipes	No Effect
Clorox Healthcare® Bleach Germicidal Wipes	No Effect
Clorox Healthcare® Hydrogen Peroxide Wipes	No Effect
Clorox™ Hydrogen Peroxide Disinfectant	No Effect
Formula 409® All Purpose Spray Cleaner (Clorox)	No Effect
Green Works™ All Purpose Spray Cleaner (Clorox)	No Effect
Clorox™ Urine Remover (The Clorox Company)	No Effect
Oxiver® Five 16 Disinfectant Cleaner (Diversey™)	No Effect
Oxivir® Tb (Diversey™)	No Effect
Virex II 256 (Diversey™)	No Effect
Virex Plus One-Step Disinfectant Cleaner & Deodorant	No Effect
Virox™ AHP 5 Disinfectant Cleaner Surface Wipes	No Effect
Virox™ 5 (Diversey™)	No Effect
Neutral Disinfectant Cleaner (Ecolab®)	No Effect
Oasis® 146 (Ecolab®)	No Effect
Oasis® Quat 144 (Ecolab®)	No Effect
OxyCide™ (Ecolab®)	No Effect
Envirocleanse A Anolite Solution	Moderate Effect
PurTabs™ - Dilution: 500 ppm (EvaClean®)	No Effect
Purell® Food Service Sanitizer (Gojo Industries)	No Effect
CaviWipes™ (Metrex)	Slight Effect

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

LUUM

Care for Decoy Vinyl (continued)

Cleaner/Disinfectant	Result
Sani-Cloth® AF3 (PDI)	No Effect
Sani-Cloth® Bleach Germicidal Wipes (PDI)	Severe Effect
Sani-Cloth® Germicidal Wipes (PDI)	Slight Effect
Sani-Cloth® HB (PDI)	No Effect
Sani-Cloth® Prime Germicidal Disposable Wipes (PDI)	No Effect
Sani-Cloth® Plus (PDI)	Severe Effect
Sani-Professional® Multi Surface Wipes (PDI)	Slight Effect
Sani-Professional® Table Turners No Rinse Wipes (PDI)	No Effect
Lysol® Spray	No Effect
Lysol® Foaming Disinfectant Cleaner	No Effect
Fade-A-Dyne® (Russ Medical Specialties)	Slight Effect
SaniZide Plus® Germicidal Solutions (Safetec of America)	Slight Effect
Fantastik Spray Cleaner® (S.C Johnson & Son, Inc.)	No Effect
Optim 33 (TB SciCan)	Slight Effect
Simple Green® (Sunshine Makers)	No Effect
Perisept (Triple S®)	No Effect
Accel® PREvention™ Concentrate (Virox® Technologies)	Slight Effect
Accel TB (Virox® Technologies)	Slight Effect
Wex-Cide (128 Wexford Labs Inc)	Severe Effect

Care for Ultra Durable Vinyl

Cleaner/Disinfectant	Result
Asepticare™ TB II (Ecolab®)	No Effect
Lysol® Foaming Disinfectant Cleaner	No Effect
Biotrol™ BirexSE® Disinfectant Concentrate	No Effect
CaviCide™ (Metrex)	No Effect
Super Sani-Cloth® 2-in-1 Wipe (PDI)	No Effect
Citrace Germicide	No Effect
Virex II 256 (Diversey™)	No Effect
Dispatch®	No Effect
Wex-Cide 128 (Wexford Labs)	No Effect
CaviWipes™ (Metrex)	No Effect
Virox™ 5 (Diversey™)	No Effect
Oxivir® Tb (Diversey™)	No Effect
Oxivir® Plus Disinfectant Cleaner Concentrate	No Effect

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

LUUM

No Effect	No change in color or surface finish.
Slight Effect	A change in color or surface finish only visible at certain angles.
Moderate Effect	A change in color or surface finish visible from all angles and directions, but does not appreciably alter the original condition of the material.
Severe Effect	A change in color or surface finish, which obviously and markedly alters the original condition of the material.

For test report showing full results, please contact customerservice@luumtextiles.com

The above evaluations are indicators after laboratory testing performed with proper cleaner/disinfectant usage.

After each application, the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue.

Improper use of cleaners/disinfectants can expedite a product failure and void warranty.

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.